



MINI SLIJPER/ MINI SCHLEIFER/ MINI GRINDER

Pos.	Description
1	Housing
2	Housing Sleeve
3	Bevel Pinion
4	Ball Bearing (2)
5	Front End Plate
6	Spacer
7	Rotor
8	Rotor Blade (4)
9	Cylinder
10	Pin
11	Rear End Plate
12	Ball Bearing (2)
13	Motor Cover
14	Valve Adaptor(PT-2276L)
15	Valve Body(PT-2276L)
16	Clamp Nut(PT-2276L)
17	Spacer(PT-2276L)
18	Controller(PT-2276L)
19	Valve Stem(PT-2276L)
20	Spring(PT-2276L)
22	Inlet Bushing(PT-2276L)
23	Safety Lever(PT-2276L)
24	Pin(PT-2276L)
25	Bevel Gear

Pos.	Description
26	Spindle
26A	Spindle (For 2276LD)
27	Spindle Cover
28	Oil Seal
29	2" Wheel Guard
30	Screw
32	Lock Screw
33	Exhaust Deflector
35	Deflector Cover
36	Screw
37	Wrench 14mm
38	Hex Wrench
40	Collet (For 2276LD)
41	Collet Nut(For 2276LD)
42	Wrench 17mm
43	Valve
44	Pin
45	Regulator Valve
45P	Washer
46	Pin
47	Spring
48	Spring
49	Regulator
50	Inlet Bushing