


BELT SANDER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	6T-620201	Housing	30	WW8	Wave Washer (WW8)
2	30102	Spring Pin (3*24L)	31	6T-620224	Flat Shoe
3	6T-620203	Air Inlet	32	6T-620221	Screw
4	6W-620304	Throttle Lever	33	59235	O-Ring (4.47*1.78)
5	6T-620205	Valve Stem	34	SP02002600	Spring Pin (2*26L)
6	61106	Valve	35	6T-620235	Bushing
7	70107	O-Ring (4.8*1.9)	36	6T-620236	Finger Pad
8	51208	Spring	37	6T-620237	Guard
9	61129	Exhaust Deflector	38	062045	Ball Bearing (2) (686ZZ)
10	70109	O-Ring (9.8*1.9)	39	6T-620248	Screw (M6*18L)
11	80209	O-Ring (12*1.6)	40	62017	Key (4*4*10)
12	62012	Spacer	41	6T-620241	Tension Bar
13	030120	Ball Bearing (608ZZ)	42	40343	Screw (M5*16L)
14	62014	Rear End Plate	43	6T-620243	Idle Pulley
15	6T-620215	Rotor	44	6T-620250	Spacer
16	62016	Rotor Blade (4)	45	6T-620244	Screw
17	6T-620107	Screw	46	6T-620146	Screw Thread Inserts (#8-32UNC*1D)
18	6T-620118	Cylinder	47	6T-620202	Guard Body
19	62019	Front End Plate	48	6T-620252	Grip
20	051220	Ball Bearing (6000ZZ)	49	51540	Safety Bar
21	62021	Cap	50	51541	Spring
22	6T-620247	Drive Pulley	51	40128-21	Spring Pin (2*16L)
23	62023	Nut (M10)	52	73107	O-Ring (9*2)
24	6T-620207	Guard Body Lock	53	6T-620208	Screw
25	6T-620211	Screw (M5*10L)	54	PN02001408	PIN (2*14.8)
26	62026	Dust Cover	55	10014	Hex. Key Wrench (4mm)
27	6T-620240	Spring	56	10010	Hex. Key Wrench (2.5mm)
28	PN05001508	Pin (5*14.8L)	57	812E12	O-Ring (33.5*2)
29	40340	Screw (M5*5L)	58	OR02607108	O-Ring (26.7*1.78)

6T-6202-0001